

Application Instructions for NCFR102

Brush, roll or spray with airless spray. Avoid WFT greater than 8 mils per coat.

Surface preparation: Surface should be prepped and/or primed.

Cure times:

Dry to recoat.....30 min.

Dry to touch.....1 hour

Dry to handle..... 4 hours

Thorough cure..... 1 week

Spread rate

16 mils WFT at 2 coats cross hatched of 8 mils WFT each.

8 mils DFT.

Coverage: 100 square feet per gallon.